










PAN SUPPORTS (OPTIONAL)




THERMOCOUPLE  
(OPTIONAL)




ETHNIC COFFEEPOT  
SUPPORT (OPTIONAL)




GLASS LID OPTIONAL  
(AVAILABLE ONLY FOR FRAMED HOBS)




COOKTOP FRAME  
(ONLY FOR TABLE-TOP HOBS)




ASSEMBLY BRACKET  
(ONLY FOR BUILT-IN HOBS)



MICRO SWITCH (OPTIONAL)



WOK BURNER



GAS HOBS IGNITION SYSTEMS